

## Parts catalog and price list of dealer

**AX-M30**

**30 LITER GEAR MIXER**

Illus. No.	PARTS NO.	PARTS NAME	QT'S
1	AXM30-01-001	UPPER LID	1 pc
2	11031-01-002	RETAINER-BEARING	1 pc
3	11012-01-003	COVER PLUG	2 pc
4	11031-01-004	GEAR HOUSE COVER	1 pc
5	GM30-01-005	CASE-TRANSMISSION	1 pc
6	XL709-11A	CONTROL PANEL	1 pc
7	GM30-01-008	REAR COVER	1 pc
8	11031-02-001	MAIN SHAFT	1 pc
9	11031-02-002	SLEEVE DRIVE	1 pc
10	11031-02-003	GEAR	1 pc
11	11031-02-004	BEVEL GEAR	1 pc
12	11031-02-005	GEAR	1 pc
13	11031-02-006	CLUTCH COPPER BUSHING	2 pc
14	11031-02-007	CLUTCH	1 pc
15	11031-02-008	GEAR	1 pc
16	11031-02-009	SPACER	1 pc
17	11031-02-010	SPACER	1 pc
18	11031-02-011	DETAIN-FIXED COVER	1 pc
19	11031-02-012	PIN	10 pc
20	11031-02-013	SPRING SHEET	10 pc
21	11031-03-001	GEAR SHAFT	1 pc
22	11031-03-002	32T GEAR	1 pc
23	11031-03-004	33T GEAR	1 pc
24	11031-03-005	23T GEAR	1 pc
25	11031-03-006	SPACER	1 pc
26	11012-03-007	OIL BAFFLE	1 pc
27	11012-04-003	WORM 4M	1 pc
28	11031-04-004	SHAFT- WORM GEAR	1 pc
29	11012-04-005	WORM GEAR 27T	1 pc
30	11031-04-007	SPACER	1 pc
31	11012-04-008	OIL BAFFLE	1 pc
32	GM20-04-009	SPACER	1 pc
33	GM30-05-001	MOTOR	1 pc
34	11012-06-001	35T BEVEL GEAR	1 pc
35	BM20-06-003	HUB ATTACHMENT	1 pc

36	11091-06-004	HOLE PLUG	1 pc
37	GM20-06-005	THUMB SCREW	1 pc
38	11012-06-006	OIL BAFFLE	1 pc
39	11031-07-001	KNOB-SHIFT HANDLE	1 pc
40	11031-07-002	SHIFT HANDLE	1 pc
41	11031-07-003	BASE ASSY- HANDLE	1 pc
42	11031-07-004	SHAFT- SHIFT ECCENTRIC	1 pc
43	11012-07-005	BRACKET- SHIFT SELECTOR	1 pc
44	11012-07-006	ECCENTRIC-SHAFT	1 pc
45	11031-07-007	SCREW	2 pc
46	11031-07-008	PLUNGER SHAFT- SHIFTER	2 pc
47	11031-07-009	FIXING SHAFT- SHIFTER	1 pc
48	GM20-07-010	SHIFT FORK	1 pc
49	11031-07-011	COMPRESSION SPRING	2 pc
50	11031-07-012	COMPRESSION SPRING	2 pc
51	11031-08-001	INTERNAL GEAR	1 pc
52	11031-08-002	GEAR	1 pc
53	11031-08-003	HEAD RING	1 pc
54	11031-08-004	PLANETARY HEAD	1 pc
55	11031-08-005	AGITATING SHAFT	1 pc
56	11031-08-006	SPACER	1 pc
57	11031-08-007	TAPERED PIN	1 pc
58	AXM30-09-001	COLUMN	1 pc
59	11031-09-002	SLIDEWAY	2 pc
60	11031-09-003	APRON	1 pc
61	11031-09-004	BASE	1 pc
62	11031-09-006	COLUMN COVER	1 pc
63	11031-09-007	PLATE	1 pc
64	11031-09-008	PANEL OF SPECIFICATIONS	1 pc
65	11031-09-009	SEAT OF CONTACTOR	1 pc
66	GM30-10-001A	BOWL CLAMP (LEFT)	1 pc
67	GM30-10-001B	BOWL CLAMP (RIGHT)	1 pc
68	11031-10-002	BOWL LOCATING PIN	2 pc
69	11031-10-003	RETAINER-BOWL	1 pc
70	11031-10-004	BOWL SUPPORT	1 pc
71	11031-11-001	LIFTING BAR	1 pc
72	11031-11-002	LIFTING HANDLE BRACKET	1 pc
73	11031-11-003	INNER ARM	1 pc

74	GM20-11-004	LIFT HANDLE	1 pc
75	11031-11-005	COMPRESSION SPRING	1 pc
76	11031-10-005	COMPRESSION SPRING	2 pc
77	11031-12-001	BOWL	1 pc
78	11031-12-002	BEATER	1 pc
79	11031-12-003	SPIRAL HOOK	1 pc
80	11031-12-004	WIRE WHIP	1 pc
81	BM30-13-001A	SEAT OF GUARD	1 pc
82	BM30-13-002A	SLIDING OPENER	1 pc
83	GM30-13-004	REAR COVER OF GUARD	1 pc
84	11031-13-003A	FIXED RING	1 pc
85	BR-5204Z	BALL BEARING	1 pc
86	BR-6205Z	BALL BEARING	2 pc
87	BR-6203Z	BALL BEARING	2 pc
88	BR-6201Z	BALL BEARING	1 pc
89	BR-6202Z	BALL BEARING	1 pc
90	BR-6204Z	BALL BEARING	1 pc
91	OS-TC32*47*10	OIL SEAL	1 pc
92	OS-TC25*40*7	OIL SEAL	1 pc
93	OS-TC28*52*10	OIL SEAL	1 pc
94			
95	CR-S19	C SNAP RING	1 pc
96	SB-6	STEEL BALL	2 pc
97	OR-G60	O RING	1 pc
98	OR-P9	O RING	1 pc
99	OR-33.5*37.5*2	O RING	1 pc
100	OR-P35	O RING	1 pc
101	KR-1/4*1/4*45	KEY	1 pc
102	KR-1/4*1/4*45	KEY	1 pc
103	KR-1/4*1/4*25	KEY	1 pc
104	KRR-5*5*30	KEY	3 pc
105	KRR-5*5*15	KEY	1 pc
106	KRR-5*5*13	KEY	1 pc
107	KRR-1/8*1/8*28	KEY	1 pc
108	TP-4*32	Tapered Pin	1 pc
109	XL709-11A	RELAY-CONTROL BOX	1 pc
110	Z15GQ22B	LIMIT SWITCH FOR GUARD	1 pc

111	Z15GQ22B	LIMIT SWITCH FOR LIFT	1 pc
112	XL710-L2	INTERNAL WIRE-PANEL/BOX	1 pc
113		INTERNAL WIRE-LIMIT SWITCH	2 pc
114	CABLE-14-3C-UL	POWER CABLE	1 pc
115	CG-20	CABLE TIE	1 pc
116		EMERGENCY STOP	1 pc
117			
118			
119	SPP-6*24	Spring Pin	2 pc
120	SPP-4*24	Spring Pin	1 pc
121	SPP-10*24	Spring Pin	2 pc
122	SPP-8*24	Spring Pin	2 pc
123	SPP-4*25	Spring Pin	2 pc
124	S+R3/16*3/8	Mac. Screw	9 pc
125	S+R3/16*1/4	Mac. Screw	14 pc
126	S+F3/16*1/2	Mac. Screw	4 pc
127	S+F3/16*3/8	Mac. Screw	6 pc
128	S-3/8*3/4	Bolt	1 pc
129	S-5/16*1/2	Bolt	2 pc
130	S-1/4*1/2	Bolt	4 pc
131	S-1/4*1/4	Bolt	4 pc
132	S-C-1/4*3/4	Cap Screw	6 pc
133	S-C-5/16*1	Cap Screw	12 pc
134	S-C-1/4*2-1/2	Cap Screw	2 pc
135	S-C-1/4*5/8	Cap Screw	1 pc
136	S-C-1/4*1	Cap Screw	6 pc
137	S-C-1/4*1/2	Cap Screw	4 pc
138	S-C-5/16*3/4	Cap Screw	6 pc
139	S-C-3/8*1	Cap Screw	4 pc
140	S-C-3/8*1-1/4	Cap Screw	4 pc
141	S-S5/16*5/8	Set Screw	1 pc
142	S-S5/16*2	Set Screw	1 pc
143	S-S5/16*3/8	Set Screw	1 pc
144	S-S5/16*5/16	Set Screw	2 pc
145	WB-1/2	Flat Washer	3 pc
146	SW-3/4	Spring Washer	1 pc
147	SW-3/8	Spring Washer	12 pc

148	SW-1/4	Spring Washer	2 pc
149	SW-5/16	Spring Washer	2 pc
150	NUT-3/4*16NF	Nut	1 pc
151	NUT-1/2*20NF	Nut	1 pc
152	NUT-3/8*16NC	Nut	3 pc
153	NUT-5/16*18NC	Nut	3 pc
154	NUT-1/2*12NC	Nut	4 pc
155	φ1/2	PLASTIC COVER	1 pc
156	AXM30-01-006	U-TYPE SEAL	1 pc
157	D11001R	STICKER OF PANEL	1 pc
	11031-E-010	CAPACITOR	1 pc