

Parts catalog

AX-M20

20 LITER GEAR MIXER

Illus. No.	PARTS NO.	PARTS NAME	QT'S
1	AXM20-01-001	TOP COVER	1 PC
2	11012-01-002	RETAINER-BEARING	1 PC
3	11012-01-003	COVER PLUG	2 PC
4	11012-01-004	GEAR HOUSE COVER	1 PC
5	AXM20-01-005	CASE-TRANSMISSION	1 PC
6	11012-01-007	RETAINER-TRANSMISSION	1 PC
7	XL709-11A	CONTROL PANEL	1PC
8	AXM20-01-006	U-TYPE SEAL	1PC
9	11012-02-005	29T GEAR	1PC
10	11012-02-006	CLUTCH COPPER BUSHING	2 PC
11	11012-02-008	38T GEAR	1PC
12	11012-02-009	WASHER	1 PC
13	11012-02-010	SPACER	1 PC
14	11012-02-016	MAIN SHAFT	1 PC
15	11012-02-017	DETAIN-FIXED COVER	1 PC
16	11012-02-018	GEAR	1 PC
17	11012-02-019	BEVEL GEAR	1 PC
18	11012-02-020	CLUTCH	1 PC
19	11012-02-021	SLEEVE DRIVE	1 PC
20	11012-02-022	WASHER	1 PC
21	11012-02-023	PIN	10 PC
22	11012-02-024	SPRING SHEET	10 PC
23	AXM20-01-008	SUPPORT OF COVER	1 PC
24	11012-03-001B	SHAFT GEAR	1 PC
25	11031-03-002	32T GEAR	1 PC
26	D11001R	STICKER OF PANEL	1 PC
27	11012-03-004	23T GEAR	1 PC
28	11012-03-007	OIL BAFFLE	1 PC
29			
30	11012-04-003	WORM 4M	1 PC
31	11012-04-004A	SHAFT- WORM GEAR	1 PC
32	11012-04-005	WORM GEAR	1 PC
33	11012-04-008	OIL BAFFLE	1 PC
34	GM20-04-009	SPACER	1 PC
35	CABLE-14-3C-UL	POWER CABLE	1 PC
36	GM20-05-001	MOTOR	1 PC
37	CG-20	CABLE TIE	1 PC

38	11012-06-001	35T BEVEL GEAR	1 PC
39	BM20-06-003	HUB ATTACHMENT	1 PC
40	11091-06-004	HOLE PLUG	1 PC
41	GM20-06-005	THUMB SCREW	1 PC
42	11012-06-006	OIL BAFFLE	1 PC
43			
44	11012-07-001	SHIFT HANDLE KNOB	1 PC
45	11012-07-002	SHIFT HANDLE	1 PC
46	GM20-07-004	ECCENTRIC SHIFT SHAFT	1 PC
47	11012-07-005	SHIFT SELECTOR	1 PC
48	11012-07-006	ECCENTRIC SHAFT	1 PC
49	11031-07-007	LOCK SCREW	2 PC
50	11031-07-008	SHIFT FORK PLUNGER	2 PC
51	11012-07-009	SHIFTER FIXED SHAFT	1 PC
52	GM20-07-010	SHIFT FORK	1 PC
53	11031-07-011	COMPRESSION SPRING	2 PC
54	11031-07-012	COMPRESSION SPRING	2 PC
55	V-153-1A5	LIMIT SWITCH	1 PC
56	11012-08-001	19T GEAR	1 PC
57	11012-08-002	INTERNAL GEAR	1 PC
58	11012-08-004	PLANETARY HEAD	1 PC
59	11012-08-005	AGITATING SHAFT	1 PC
60	11012-08-006	HEAD RING	1 PC
61	11012-08-007	TAPERED PIN	1 PC
62	11012-13-006B	SEAT OF LIMIT SWITCH OF GUARD	1 PC
63	11012-09-001B	COLUMN	1 PC
64	AXM20-01-007	REAR COVER-MIXER HEAD	1 PC
65	S+R3/16*1/4	MAC. SCREW	2 PC
66	11012-09-004	BASE	1 PC
67	GM20-09-005	FRONT COVER-COLUMN	1 PC
68	SHL-Q2155	LIMIT SWITCH OF GUARD	1 PC
69	GM20-10-001	BOWL SUPPORT	1 PC
70	11012-10-002	BOWL PIN	2 PC
71	11012-10-006A	BOWL LOCKING PLATE (LEFT)	1 PC
72	11012-10-006B	BOWL LOCKING PLATE (RIGHT)	1 PC
73	GM20-11-001	LIFTING BAR	1 PC
74	BM10-11-002	L PLATE	1 PC
75	11012-11-003	LIFTING HANDLE BRACKET	1 PC
76	GM20-11-004	LIFTING HANDEL	1 PC
77	11012-11-005	COMPRESSION SPRING	1 PC

78	11012-12-001	BOWL	1 PC
79	11012-12-002	BEATER	1 PC
80	11012-12-003	HOOK	1 PC
81	11012-12-004	WIRE WHIP	1 PC
82	11012-13-006B	SEAT OF LIMIT SWITCH OF LIFT	1 PC
83	11012-13-001	SEAT OF SAFETY GUARD	1 PC
84	GM20-13-002S	SLIDING OPENER	1 PC
85	11012-13-003A	FIXED RING	1 PC
86		SEAT OF CONTROL BOX	1 PC
87	BR-6203Z	BR-6203Z	2 PC
88	BR-6005Z	BR-6005Z	1 PC
89	BR-6200Z	BR-6200Z	4 PC
90	BR-6204Z	BR-6204Z	1 PC
91	SB-6	SB-6	2 PC
92	OR-G60	OR-G60	1 PC
93	OR-33.5*37.5*2	OR-33.5*37.5*2	1 PC
94	OR-P35	OR-P35	1 PC
95	OS-TC32*47*10	OS-TC32*47*10	1 PC
96	OS-TC25*40*07	OS-TC25*40*07	1 PC
97	OS-TC25*47*08	OS-TC25*47*08	1 PC
98	CR-S16	CR-S16	1 PC
99	CR-S20	CR-S20	1 PC
100	CR-R47	CR-R47	1 PC
101	OS-TC25*32*04	OS-TC25*32*04	1 PC
102	SPP-8*25	SPP-8*25	2 PC
103	SPP-6*22	SPP-6*22	2 PC
104	SPP-4*24	SPP-4*24	1 PC
105	TP-4*32	TP-4*32	1 PC
106	YP-1/8*20	YP-1/8*20	1 PC
107	SPP-8*20	SPP-8*20	2 PC
108	KRR-6*6*30	KRR-6*6*30	2 PC
109	KRR-1/8*1/8*1/2	KRR-1/8*1/8*1/2	2 PC
110	KRR-5*5*15	KRR-5*5*15	1 PC
111	KRR-1/8*1/8*28	KRR-1/8*1/8*28	1 PC
112	KR-6*6*50	KR-6*6*50	1 PC
113	KR-5*5*20	KR-5*5*20	1 PC
114	S-3/8*1-1/4	Bolt 3/8*1-1/4	2 PC
115	S+R1/4*2	LONG BOLT	2 PC
116	S-1/2*1/2	Bolt 1/2*1/2	2 PC
117	S-3/8*1	Bolt 3/8*1	4 PC

118	S+R3/16*3/8	MAC. SCREW	6 PC
119	S-1/4*2	Bolt	2 PC
120	S-C-1/4*5/8	CAP SCREW	8 PC
121	S-C-5/16*1	CAP SCREW	4 PC
122	S-C-5/16*1	CAP SCREW	4 PC
123	S-C-1/4*5/8	CAP SCREW	2 PC
124	S-C-1/4*1-1/4	CAP SCREW	6 PC
125	S-S5/16*2	SET SCREW	1 PC
126	S-S5/16*3/4	SET SCREW	1 PC
127	S-S5/16*1/4	SET SCREW	2 PC
128	S+F3/16*1/2	MAC. SCREW	4 PC
129	S+R3/16*3/8	MAC. SCREW	18 PC
130	S+R1/4*3/8	MAC. SCREW	3 PC
131	S+R5/32*3/8	MAC. SCREW	1 PC
132	NUT-1/2*20NF	Nut	3 PC
133	NUT-3/4*16NF	Nut	1 PC
134	NUT-3/8*24NF	Nut	2 PC
135	NUT-3/8*16NC	Nut	6 PC
136	NUT-1/4*20NC	Nut	2 PC
137	S+R3/16*3/8	MAC. SCREW	2 PC
138	XL709-11A	RELAY-CONTROL BOX	1 PC
139	WB-3/8	FLAT WASHER	3 PC
140	WB-1/4	FLAT WASHER	2 PC
141	SW-5/16	SPRING WASHER	4 PC
142	SW-1/4	SPRING WASHER	2 PC
143	SW-3/8	SPRING WASHER	15 PC
144	SW-1/2	SPRING WASHER	2 PC
145	SW-3/4	SPRING WASHER	1 PC
146	CP-200UF	CAPACITOR	1 PC
147	11012-05-006/60HZ	GOVERNOR PLATE	1 PC
148	11012-05-007/60HZ	GOVERNOR	1 PC
149	XL710-L2	INTERNAL WIRE-PANEL/BOX	1 PC
150		INTERNAL WIRE-LIMIT SWITCH	1PC